

# EQUINOX

## **Multiport Serial I/O Adapter Hardware Reference Guide**

includes:

SST-2I - PN 990286  
SST-4I - PN 990283  
SST-4P - PN 990299  
SST-4E - PN 990285  
SST-8I - PN 990265  
SST-8P - PN 990301  
SST-8E - PN 990266

***SuperSerial Technology***

---

# Contents

Overview
Installation
PCI Setup
ISA Setup
EISA Setup
ISA Installation Tips
PCI Installation Tips
Connecting and Cabling Information
Connector Panel and Fan Out Cables
CP-8 and DB-25 Fan Out Cable to Device Cabling
RJ-45 Fan Out Cable to Device Cabling
DB-9 to Device Cabling
RJ-45 Modular Adapters


---

## Overview

Equinox SuperSerial Technology (SST) Adapters are intelligent, high-speed (up to 920k bps on each port) *Multiport Adapters* providing high performance serial I/O solutions for PCI, ISA and EISA bus systems. All port interfaces are standard RS-232 with full modem control and voltage surge protection on every pin.

SST Adapters appear to the system host processor as memory. That is, they are memory mapped devices. Each adapter is automatically mapped into system memory at the time of device driver installation. The device driver soft-configures all adapters each time the system is initialized (booted). See the appropriate software documentation located on your SuperSerial CDROM for detailed device driver information.

The SST Adapter (see Figure 1 below) occupies a slot in the host computer and provides the intelligent functions to "off-load" the CPU serial communications processing tasks. Adapters are available for PCI, ISA and EISA bus systems.



**Figure 1. SST Multiport I/O Adapter (SST-81 and SST-8P Shown)**

---

## Installation

Use the following procedure to install your SST Adapter. Alternatively, you may follow the installation instructions presented in your host system documentation.

1. Set the host computer system power switch to OFF and disconnect the power cord.
2. Locate a free expansion slot.
3. Insert and secure the adapter firmly into the expansion slot.
4. Replace the power cord and turn the host computer system ON.
5. Install the device driver software (see CDROM for details).

---

## PCI Setup

Peripheral Component Interconnect (PCI) system architecture has a design feature termed *Plug and Play*. This feature automatically detects, identifies and configures the currently installed devices each time the system is booted. Therefore, whenever an adapter is installed (or removed) in a PCI system, the adapter is recognized and configured immediately upon restart.


---

## ISA Setup

All ISA Adapters must be assigned a unique I/O base address. This can be accomplished by the use of ISA Plug and Play (PnP) or the I/O Base Address Switch S1 (see Figure 1 and Table 1).

If PnP is not supported by your operating system, or if you are unsure, place the PnP Jumper (JP1) in the position closest to switch S1. This will disable PnP and enable the sixteen position I/O Base Address switch (see Table 1 below).

If multiple ISA Adapters are installed in the same system, a different I/O base address must be assigned to each adapter. (This is automatically accomplished if PnP is utilized.) This procedure should be performed before the adapter is physically installed.



1	2	3	4	Base Address
OFF	OFF	OFF	OFF	200
ON	OFF	OFF	OFF	220
OFF	ON	OFF	OFF	240
ON	ON	OFF	OFF	260
OFF	OFF	ON	OFF	280
ON	OFF	ON	OFF	2A0
OFF	ON	ON	OFF	2C0
ON	ON	ON	OFF	2E0
OFF	OFF	OFF	ON	300
ON	OFF	OFF	ON	320
OFF	ON	OFF	ON	340
ON	ON	OFF	ON	360
OFF	OFF	ON	ON	380
ON	OFF	ON	ON	3A0
OFF	ON	ON	ON	3C0
ON	ON	ON	ON	3E0

**Table 1. Switch S1 Is Shown Set For I/O Base Address 240H**

---

## EISA Setup

All Equinox configuration files are located on the SuperSerial CDROM. All directories below assume that D: is the CDROM drive.

Novell, DOS, OS/2,	D:\Drivers\RAS\Disk1
Windows based	D:\Drivers\RAS\Disk3
UNIX based	D:\Drivers\UNIX\DIAG_DOS

Copy all .cfg files from CDROM directory to your system manufacturers EISA configuration diskette. Then run EISA configuration to correctly identify the Equinox adapters.

---

## ISA Installation Tips

SST ISA adapters require a 16K window (below 1 megabyte) in the host system memory. Occasionally the driver may not be able to automatically find an available memory window (i.e. memory hole) due to system caching, memory shadowing, or devices that stay hidden in memory until loading.

If the driver fails to locate the adapter after installation you may need to manually configure its memory address. Check for available memory holes by using the SSDIAG.EXE /M software located on your SuperSerial CDROM. (Refer to SSDIAG.DOC about the command line switch "/M"). Then configure the driver to use one of the available memory holes between 0xA0000 and 0xEFFFFF. (Refer to the software driver documentation located on the CDROM for information on how to manually configure this memory range.)

If SSDIAG /M reports that there are no available memory holes you may need to modify your system BIOS to disable memory shadowing or caching (in the 0xA0000 to 0xEFFFFF range). Also, some system BIOS will allow you to open a memory hole for ISA memory mapped devices.

---

## PCI Installation Tips

A PCI adapter may have trouble locating available memory addresses on some systems that have shared PCI slots. If this happens move the PCI adapter to a non-shared slot or change the slot type in the system BIOS to a master PCI slot.

# Connecting and Cabling Information

SST-2I adapters have two DB-9s on the connector bezel as shown in Figure 2 below. See Figures 13-15 for detailed cabling information.




Figure 2. SST-2I Multiport I/O Adapter

Figure 3 below shows the pinouts for the SST-2I DB-9 Connectors.

SST-2 DB-9 Pin Outs				
DB-9 Pin Numbers	Signal Name	DB-9 Pin Functions		
5	(GND) Ground			
6	(RI) Ring Indicator	Input	←	
4	(DTR) Data Terminal Ready	Output		→
8	(CTS) Clear To Send	Input	←	
3	(TD) Transmit Data	Output		→
7	(RTS) Request To Send	Output		→
2	(RD) Receive Data	Input	←	
9	(DSR) Data Set Ready	Input	←	
1	(CD) Data Carrier detect	Input	←	

Figure 3. SST-2I DB-9 Pinouts

SST-4 and SST-8 adapters require a fan out cable or a connector panel (ordered separately). See pages 6 through 10 for detailed cabling and ordering information.

# Connector Panel and Fan Out Cables

SST Connector Panels (CPs) and Fan Out Cables (FOCs) provide four or eight RS-232 interfaces. Table 2 below details products available from Equinox. Figures 4 through 6 show the connector panel and pinouts for CP-8, DB-25 and RJ-45 fan out cables.

P/N	Name	Description	Connector Type
690269	F04-DB	SST-4 Fan Out Cable	DB-25 Male
690268	F04-RJ	SST-4 Fan Out Cable	RJ-45 Female
690293	F04-DB9	SST-4 Fan Out Cable	DB-9 Male
690264	F08-DB	SST-8 Fan Out Cable	DB-25 Male
690265	F08-RJ	SST-8 Fan Out Cable	RJ-45 Female
690271	F08-DB9	SST-8 Fan Out Cable	DB-9 Male
990343	CP-8	SST-8 Connector Panel	DB-25 Female

Table 2. SST Connector Accessories




Figure 4. SST Fan Out Cable and Connector Panel

Fan Out Cable	Signal Name	Pin Functions
Male DTE DB-25	1 GND Chassis Ground	Ground
	2 TD Transmit Data	Output
	3 RD Receive Data	Input
	4 RTS Request To Send	Output
	5 CTS Clear To Send	Input
	6 DSR Data Set Ready	Input
	7 GND Signal Ground	Ground
	8 DCD Data Carrier Detect	Input
	20 DTR Data Terminal Ready	Output
	22 RI Ring Indicator	Input
CP-8 Connector Panel		
Female DTE DB-25		

Figure 5. DB-25 Fan Out Cable and Connector Panel Pinouts

	Signal Name	Pin Functions
	1 RI Ring Indicator	Input
	2 RTS Request To Send	Output
	3 DTR Data Terminal Ready	Output
	4 RD Receive Data	Input
	5 GND Signal Ground	Ground
	6 TD Transmit Data	Output
	7 GND Signal Ground	Ground
	8 DCD Data Carrier Detect	Input
	9 CTS Clear To Send	Input
	10 DSR Data Set Ready	Input

Figure 6. RJ-45 Fan Out Cable Pinouts

## CP-8 and DB-25 Fan Out Cable to Device Cabling

Figures 7 through 9 show the pinouts required to make a cable to connect between SST CP-8 and DB-25 FOC ports and your terminals, printers, modems, etc. Note that CP-8s will require a cable with a male DB-25 connector not a female as shown in the figures.




Figure 7. Cable Pinouts for FOC DB-25 to Terminal/Printer DB-25




Figure 8. Cable Pinouts for FOC DB-25 to PC DB-9




Figure 9 Cable Pinouts for FOC DB-25 to Modem DB-25



# RJ-45 Fan Out Cable to Device Cabling

Figures 10 through 12 show the pinouts required to make a cable to connect between SST RJ-45 FOC ports and your devices.




Figure 10. Cable Pinouts for FOC RJ-45 to Terminal/Printer DB-25




Figure 11. Cable Pinouts for FOC RJ-45 to PC DB-9




Figure 12. Cable Pinouts for FOC RJ-45 to Modem DB-25

# DB-9 to Device Cabling

Figures 13 through 15 show the pinouts required to make a cable to connect between SST DB-9 ports and your devices.




Figure 13. Cable Pinouts for SST DB-9 to Terminal/Printer DB-25




Figure 14. Cable Pinouts for SST DB-9 to PC DB-9




Figure 15. Cable Pinouts for SST DB-9 to modem DB-25

# RJ-45 Modular Adapters

Modular Adapters are available from Equinox to convert RJ-45 modular jacks to DB-25 or DB-9 connectors. These modular adapters in conjunction with 10-wire modular cables perform the same functions as shown in Figures 10 through 12. Table 3 below describes the modular adapters available from Equinox.

P/N	Connector	Connects To
210070	DB-25 DCE Male	Terminal or Printer (Female)
210071	DB-25 DCE Female	Terminal or Printer (Male)
210068	DB-25 DTE Male	Modem or Multiplexer (Female)
210069	DB-25 DTE Female	DCE Devices (Male)
210072	DB-9 Female	DB-9 PC (Male)

Table 3. 10-wire Modular Adapters

The adapters listed above (with 10-wire modular cables as shown below) may be used to attach devices to SST RJ-45 FOC ports. If a customer supplied modular cable is used, make sure the cable is reversing (see Figure 16 below).




Figure 16. 10-wire RJ-45 Reversing Cable

The following modular cables are available from Equinox (use with modular adapters from Table 3 above):

P/N	Description
690252	10' 10-Wire Reversing Modular Cable
690253	25' 10-Wire Reversing Modular Cable
690254	75' 10-Wire Reversing Modular Cable

Table 4. 10-wire Modular Cables

# DECLARATION OF CONFORMITY

according to ISO/IEC Guide 22 and EN 45014

**Manufacturer's Name:** Equinox Systems Inc.  
**Manufacturer's Address:** One Equinox Way  
Sunrise, Florida 33351-6709  
USA

**declares, that the products**

**Product Names:** SuperSerial Technology (SST)  
Serial I/O products  
Megaplex Serial I/O products  
ELS Ethernet Terminal Servers

**Model Numbers:** SST-2, SST-4, SST-8, SST-64,  
SST-128, PM-8, PM-16, MIM-1,  
CMX-16, SSM-8, SSM-12, SSM-24  
Megaplex, Megaplex CMX  
ELS-8, ELS-16

**Product Options:** All

**conform to the following Product Specifications:**

Safety: EN 60950:1992, CSA C22.2 No:950, UL 1950  
EMC: EN 55022 (CISPR22 A): 1987E,  
FCC Part 15 Class A  
EN 50082-1: 1992 - Generic Immunity  
IEC 801-2: 1984, 8kV CD, 8kV AD  
IEC 801-3: 1984, 3V/m, 27-500MHz  
IEC 801-4: 1988, 1kV Power & 0.5kV I/O Lines

## Supplementary Information:

The products herewith comply with the requirements of the Low Voltage Directive, 73/23/EEC and the EMC Directive 89/336/EEC, including amendments by the CE-marking Directive 93/68/EEC.

March, 1999

Equinox Systems, Inc.

© 1999 Equinox Systems Inc. All rights reserved. Reproduction without permission prohibited.

Equinox, Megaport, Megaplex, and SuperSerial are registered trademarks of Equinox Systems Inc. All other brands and product names are trademarks of their respective holders.

Equinox makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Information is subject to change without notice and does not represent a commitment on the part of Equinox Systems Inc.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**SuperSerial Technology  
Multiport Serial I/O Adapter  
Hardware Reference Guide  
560160/B (March 1999)**

Equinox Systems Inc.  
One Equinox Way  
Sunrise, Florida 33351-6709  
(954) 746-9000  
Fax: (954) 746-9101  
[ftp.equinox.com](ftp://ftp.equinox.com)  
[www.equinox.com](http://www.equinox.com)  
[support@equinox.com](mailto:support@equinox.com)